



**SHERWIN
WILLIAMS®**

SUPERPAINT®
Exterior Latex High Gloss

A85W00507 Super White
A85W00051 Extra White
A85W00053 Deep Base
A85T00054 Ultradeep Base



As of 11/20/2017, Complies with:			
OTC	Yes	LEED® 09 NC CI	N/A
OTC Phase II	Yes	LEED® 09 CS	N/A
SCAQMD	No	LEED® v4 Emissions	N/A
CARB	Yes	LEED® v4 VOC	No
CARB SCM2007	Yes		
Canada	Yes	MPI	

CHARACTERISTICS

SuperPaint Exterior Latex High Gloss, with improved resistance to early dirt pick up, provides outstanding performance on properly prepared aluminum and vinyl siding, wood, hardboard, masonry, cement, brick, block, stucco, and metal.

VinylSafe™ paint colors allow you the freedom to choose from 100 color options, including a limited selection of darker colors formulated to resist warping or buckling when applied to a sound, stable vinyl substrate.

Recommended for:

- Doors
- Windows
- Trim
- Shutters

Excellent Performance in:

- Block Resistance
- Moisture Resistance
- Gloss Retention
- Flow and Leveling

Color: Most colors
To optimize hide and color development, always use the recommended P-Shadow primer

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet: 1.8 mils dry

Drying Time, @ 77°F, 50% RH:
Touch: 1 hour
Tack Free: 4 hours
Recoat: 18 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 70+ units @ 60°

Tinting with CCE:

Base	oz/gal	Strength
Extra White	0-6	SherColor
Deep Base	4-12	SherColor
Ultradeep Base	10-12	SherColor

Extra White A85W00051
(may vary by base)

VOC (less exempt solvents):
90 g/L; 0.75 lb/gal
As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 44 ± 2%
Weight Solids: 53 ± 2%
Weight per Gallon: 9.87 lb
Flash Point: N/A
Vehicle Type: Acrylic

Mildew Resistant
This coating contains agents which inhibit the growth of mildew on the surface of this coating film.

SPECIFICATIONS

SuperPaint Exterior Latex can be self-priming when used directly over existing coatings, or bare drywall, plaster and masonry (with a cured pH of less than 9). The first coat acts like a coat of primer and the second coat provides the final appearance and performance. Please note that some specific surfaces require specialized treatment.

Aluminum & Aluminum Siding, Galvanized Steel, Vinyl Siding

2 cts. SuperPaint Exterior Latex
Concrete Block, CMU, Split face Block

1 ct. Loxon Block Surfacers
2 cts. SuperPaint Exterior Latex
Brick

1 ct. Loxon Conditioner
2 cts. SuperPaint Exterior Latex
Cement Composition Siding/Panels

1 ct. Loxon Concrete & Masonry Primer or Loxon Conditioner
2 cts. SuperPaint Exterior Latex
Stucco, Cement, Concrete

1 ct. Loxon Concrete & Masonry Primer
2 cts. SuperPaint Exterior Latex
Plywood

1 ct. Exterior Latex Wood Primer
2 cts. SuperPaint Exterior Latex
Wood (Cedar, Redwood)¹

1 ct. Exterior Oil-Based Wood Primer
2 cts. SuperPaint Exterior Latex

¹ Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. For best results on these woods, use a coat of Exterior Oil-Based Wood Primer.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Aluminum and Galvanized Steel
Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

Caulking
Gaps between windows, doors, trim, and other through-wall openings can be filled with the appropriate caulk after priming the surface.

Cement Composition Siding/Panels
Remove all dirt, dust, grease, oil, loose particles, laitance, foreign material, and peeling or defective coatings. Allow the surface to dry thoroughly. If the surface is new, test it for pH, if the pH is higher than 9, prime with Loxon Concrete & Masonry Primer.



SUPERPAINT[®]

Exterior Latex High Gloss

A85W00507 Super White
 A85W00051 Extra White
 A85W00053 Deep Base
 A85T00054 Ultradeep Base

<u>SURFACE PREPARATION</u>	<u>SURFACE PREPARATION</u>	<u>CAUTIONS</u>
<p>Masonry, Concrete, Cement, Block All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer. Cracks, voids, and other holes should be repaired with an elastomeric patch or sealant.</p> <p>Steel Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed the same day as cleaned.</p> <p>Stucco Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.</p> <p>*Vinyl or other PVC Building Products Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, prime with appropriate white primer. Do not paint vinyl with any color darker than the original color or having a Light Reflective Value (LRV) of less than 56 unless VinylSafe[®] Colors are used. If VinylSafe colors are not used the vinyl may warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.</p> <p>Wood, Plywood, Composition Board Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All new and patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.</p>	<p>Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p style="text-align: center;"><u>APPLICATION</u></p> <p>Apply at temperatures above 50°F. No reduction needed.</p> <p>SuperPaint Exterior Latex High Gloss sets up very quickly, providing painted surfaces which resists sticking together (blocking). When used at normal temperature and humidity, windows and doors can be closed after 4 hours drying. Maximum blocking resistance is achieved after 24 hours. With this benefit, some adjustments to your painting approach must be made.</p> <ul style="list-style-type: none"> • Do not paint in direct sun. Temperatures over 80°F and humidity under 30% will make the paint set up quicker. • Do not over-work the product. Load paint on the surface, spread to cover, smooth out with long, even strokes. Finish this area before moving to a new area. Do not attempt to brush back into and further uniform an area once finished. • Work quickly to maintain a wet edge. • Paint objects in a vertical position to reduce the collection of airborne dirt and dust on the drying paint. <p>Brush Use a nylon/polyester brush.</p> <p>Roller 3/8" - 3/4" nap synthetic cover</p> <p>Spray—Airless Pressure2000 psi Tip......013"-.017"</p>	<p><u>CAUTIONS</u></p> <p>For exterior use only. Protect from freezing. Non-photochemically reactive. Not for use on floors.</p> <p>Before using, carefully read CAUTIONS on label.</p> <p>HOTW 11/20/2017 A85W00051 22 90 Viet, KOR</p> <p style="text-align: center;"><u>CLEANUP INFORMATION</u></p> <p>Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with a compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>