

Product Data Sheet

Technical Information

Finish: Flat 0-7 @ 85°

Colors: Bright White, Bases,

Custom Tints

Drying Time (@ 50% Rel. Humidity)

35-45°F 45-60°F 77°F+

To Touch: 2 Hrs 2 Hrs 30 Min To Recoat: 24-48 Hrs 5 Hrs 4 Hrs

Spread Rate: 300-400 Sq. Ft. /Gal

(dependent upon surface texture and porosity)

Film Thickness: 4.0 mils wet

1.0 mils dry

Volume Solids: $26\% \pm 2\%$

Weight Solids: $43\% \pm 2\%$

Weight per Gallon: 10.87 lbs

Vehicle Type: Acrylic

Flash Point: Not Applicable

V.O.C. Level: VOC< 50 g/l- 0.35 lb/gal

as per 40 CFR 59.406

Reduction: Water

Cleanup: Soap and Water

Size: Available in Ones and

Fives*

(*select SKUS in Fives)

Warranty:

20 YEAR LIMITED WARRANTY: If this product, when applied according to label instructions, fails to perform to your complete satisfaction, upon presentation of proof of purchase to the store where the product was purchased we will, as your exclusive remedy, either replace an equivalent quantity of product free of charge or refund the purchase price. This warranty covers paint that is applied according to label instructions and excludes failure due to improper surface preparation, structural defects, or failure of the previous paint. This warranty does not include (1) labor or costs associated with labor for the application of any product and/or (2) any indirect, special, incidental or consequential dam ages with labor for the application of any product and/or (2) any indirect, special, incidental or consequential damages.

5000

Exterior Flat 100% Acrylic Water Base House Paint

Conco® 5000 Series Exterior Flat 100% Acrylic Water Base House Paint is our best quality professional grade paint ideal for Commercial Property, Residential Re-Paints, Siding and Masonry.

Recommended Uses

- Commercial Property
- Residential Re-Paints
- Wood Siding
- Aluminum & Vinyl Siding
- Metal
- Rustic or Sawn Wood
- Vertical Shakes & Shingles
- Previously Painted Surfaces
- Concrete, Masonry & Stucco

Performance Benefits

- 100% Acrylic
- Excellent Durability
- Outstanding Adhesion
- Excellent Color Retention
- Great Hide
- Applies in Temperatures as Low as 35°
- Easy Application
- Brush, Roll or Spray
- Tintable to More Than 1.000 Colors

Recommended Systems

New Wood, Preprimed Fiberboard, Hardboard, Redwood, Cedar

1 coat Conco® P009 Exterior Oil Base Wood Stain Blocking Primer, or 1 coat Conco® P007 Int/Ext All Surface Acrylic Stain Blocking Primer 1 or 2 coats Conco® 5000 Series Exterior Flat Acrylic

Masonry (allow to cure for 30 days)

1 coat Conco® P007 Int/Ext All Surface Acrylic Stain Blocking Primer 1 or 2 coats Conco® 5000 Series Exterior Flat Acrylic

Aggregate Block

1 coat Conco® P9511 Int/Ext Acrylic Latex Block Filler 1 or 2 coats Conco® 5000 Series Exterior Flat Acrylic

Meta

1 coat Conco® P007 Int/Ext All Surface Acrylic Stain Blocking Primer 1 or 2 coats Conco® 5000 Series Exterior Flat Acrylic

Vinyl Siding, Aluminum Siding

1 or 2 coats Conco® 5000 Series Exterior Flat Acrylic

Surface Preparation

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Preparation

To ensure proper adhesion, all surfaces must be clean, dry and free from dirt, wax, grease, oil, chalk, mildew and loose or peeling paint. Nail holes, cracks and other surface imperfections should be properly filled, sanded smooth and dusted clean. All mildew and mold must be completely and thoroughly removed. Glossy surfaces must be sanded and dusted clean. Always wear a properly selected and fitted NIOSH/MSHA approved dust mask or respirator when sanding.

New Wood, Pre-primed Fiberboard, Hardboard, Cedar, Redwood

Sand any exposed wood to a fresh, smooth surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Remove all sanding dust. Two coats of primer may be necessary on cedar and redwood to block tannins.

Masonry/Aggregate Block (allow to cure for 30 days)

Remove all surface contamination, including heavy chalk, efflorescence, laitance and concrete dust, by washing with an appropriate cleaner and allow to dry. If necessary, pressure wash with a 2100 psi, rinse thoroughly and allow to dry. Remove all form release and curing agents.

Metal

Wash with an appropriate cleaner to remove any surface contamination. Remove all corrosion with sandpaper, steel wool or other abrading method. Prime bare steel the same day as cleaned.

Caulking

Fill gaps between walls, ceilings, crown moldings and other trim with latex or siliconized latex caulk after priming the surface.

Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

Cleanup Information

Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.



5000

Exterior Flat 100% Acrylic Water Base House Paint

Application

Do not apply at air, surface or product temperatures below 35°F or when air or surface temperatures may drop below 35°F within 24 hours.

Spray - Airless

Brush

Use a quality nylon/polyester brush.

Rolle

Use a 3/8" nap synthetic roller cover.

Tips for Better Performance

- Stir well before using
- If using more than one package of the same color, mix together before applying to ensure uniform color
- Clean the surface thoroughly
- Sand surface smooth to ensure an even surface
- Prepare the substrate to create a uniform surface
- Patch cracks, crevices and through-wall openings using proper sealant or patch
- Fill voids and openings around windows and doors using proper sealant or patch
- Caulk as needed using quality latex or siliconized latex caulk or sealant

Cautions

- For exterior use only
- Keep from freezing
- Not for use on roofs, floors or decks
- Not for use on horizontal surfaces where water may collect

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Conco Paints. Information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Conco Paint retailer or sales representative to obtain the most recent Product Data Sheet.