



**SHERWIN  
WILLIAMS.**

# DECKSCAPES™

## DECK WASH

### Deck Wash

Bring back the fresh, natural look of your deck with Deck Wash. Enjoy the self working, no scrub formulation. This product is an excellent choice to restore your surface or to use as a pretreatment for staining, preserving, or sealing.

#### Where to use:

Use on decks and outdoor furniture made of pressure treated wood, cedar, pine, and most other woods. This product is not recommended for teak. This product is intended for exterior use only.

#### Coverage:

One gallon covers approximately 200-300 square feet, depending on the condition of the surface.

#### Preparation:

Before applying overall, test a sample area, rinse, and let dry to ensure that the results are to your satisfaction. Make sure the surface is completely dry prior to and during application. If the wood is previously damaged due to pressure washing or significant weathering has taken place, the surface may appear fuzzy after application.

#### Directions for use:

Use at full strength. Apply to the surface with a sprayer or plastic sprinkling can. After applying, let the product sit on the surface for 10 minutes (no longer than 15 minutes). During this time, the product is working to remove the dirt and contamination embedded in the pores of the wood. For stubborn stains, it may be advantageous to scrub with a stiff brush or broom for best results. After 10 minutes, rinse the surface thoroughly with clean water. Repeat the rinsing 2 or 3 times. If topcoating is desired, wait at least 24 hours until the surface is completely dry before applying a product from the DeckScapes Deck Care Family.

#### Cautions:

This product does not contain any acids or phosphates. When used according to label instructions, this is not harmful to plants or animals.

Active ingredient is Sodium Hypochlorite.

See label for safety precautions.

### SURFACE PREPARATION

Using the right cleaner often makes the cleaning easier. Prior to using Deck Wash, some general cleaning may be needed. Clean all surfaces completely with the appropriate cleaner based on the conditions. Rinse the surface completely and allow the surface to dry thoroughly.

**Cleaner** ..... Condition

#### **ProClean® PrepWash Concentrate**

Light to moderate surface dirt  
Barbecue grease

#### **ProClean® Mildew Eliminator**

Mildew

#### **DeckScapes™ Stain & Sealer Remover**

Weathered, gray wood  
Old Paint & Stain

#### **DeckScapes™ Deck Wash**

Mildew stain  
Algae stain  
Weathered wood (bleaches wood)  
Gray wood (bleaches wood)

#### **DeckScapes Revive®**

Tannin Bleed  
Nail stain  
Weathered wood (restores color)  
Gray wood (restores color)  
Mill Glaze

The information, ratings, and opinions stated here pertain to the material offered at the time of publication and represent the results of tests believed to be reliable. Published technical data and instructions are subject to change.



**SHERWIN  
WILLIAMS.**

--	--