



**SHERWIN
WILLIAMS.**

DECKSCAPES™ REVIVE®

DECK & SIDING BRIGHTENER

DESCRIPTION

DeckScapes Revive Deck & Siding Brightener is a fast-acting, ready-to-use cleaner specially formulated for cedar, redwood and other highly resinous exterior woods as well as dense woods such as mahogany. Due to the chemical characteristics of these types of woods, traditional cleaners can leave the surface with an unnatural, darkened appearance. DeckScapes Revive Deck & Siding Brightener will help remove dirt and unsightly stains caused by mildew and algae, gray and weathered wood, tannin bleed and nail bleed as well as stubborn mill glaze (a surface barrier to wood coatings found on most newly installed cedar and redwood) and restore the surface to its bright, clean natural look.

Where to use:

DeckScapes Revive Deck & Siding Brightener can be used on any new or existing exterior structure including wood decks, fences, siding, shakes, shingles, boat docks, boardwalks, outdoor furniture, picnic tables, hot tubs, planters, benches, trellises and gazebos.

CHARACTERISTICS

Coverage: Approximately 150-250 sq ft/gal
 Appearance: Water white, turbid
 pH: 1
 Solvent: Water
 Weight per Gallon: 8.54 lb

SURFACE PREPARATION

Thoroughly wet plants and shrubs surrounding wood structure to be cleaned and cover to protect from overspray. Remove all deck furniture and decorative items. Do not allow DeckScapes Revive Deck & Siding Brightener to come into contact with finished or aluminum surfaces. Be sure wood is free of any loose dirt and debris. If surface is extremely dry or in direct, hot sunlight, dampen with water. Wear rubber gloves and eye protection. Do not allow DeckScapes Revive Deck & Siding Brightener to come into prolonged contact with clothing, carpet, or fabric, as damage may occur. Plan the application: for vertical surfaces, work from the bottom to the top. Treat small areas at a time. Exercise caution when working on wet surfaces as they may be slippery. Avoid spraying on windy days.

APPLICATION

Use in a well ventilated area and only as directed.

On a horizontal surface, apply the mixture with a pump sprayer, brush or mop; on a vertical surface (siding or fencing) apply with a pump-up sprayer or deep nap roller working from the bottom to the top of the structure. Coat only 5-10 boards (20 sq. ft.) at a time to maintain adequate surface wetness and allow concentration of cleaning efforts to an area. Immediately and thoroughly rinse any overspray or accidental spills with water. Allow DeckScapes Revive Deck & Siding Brightener to set on the surface for 10-15 minutes. For best results, lightly scrub surface with a stiff, synthetic bristle brush. Do not allow DeckScapes Revive Deck & Siding Brightener to completely dry during application.

Thoroughly rinse the surface with fresh water from a hose, removing all residue. Any residue left on the surface may interfere with the drying or adhesion of topcoats.

Rinse surrounding area and vegetation with water.

Stubborn stains or missed areas may need to be scrubbed with additional solution and rinse again. Allow 2-3 days, depending on weather conditions, to allow the wood to thoroughly dry before applying a protective finish.

CLEAN UP INFORMATION

Rinse equipment and brushes with soap and water immediately after use.

CAUTION

CONTAINS OXALICACID. Causes eye and skin irritation. Avoid contact with eyes and prolonged contact with the skin. Avoid breathing mist. Wash thoroughly after handling. **USE ONLY WITH ADEQUATE VENTILATION.**

FIRST AID: Eye contact: Immediately flush eyes with plenty of water for at least 15 minutes. Seek prompt medical attention. Skin Contact: Wash area immediately with soap and water. Remove contaminated clothing. Wash clothing before re-use. Inhalation: If you experience difficulty in breathing, leave area to obtain fresh air. If continued difficulty is experienced, seek medical attention. Ingestion: Give large quantities of milk. Call physician immediately.

105.49

DECKSCAPES™

REVIVE®

DECK & SIDING BRIGHTENER



**SHERWIN
WILLIAMS®**

SURFACE PREPARATION

Using the right cleaner often makes the cleaning easier. Prior to using Revive, some general cleaning may be needed. Clean all surfaces completely with the appropriate cleaner based on the conditions. Rinse the surface completely and allow the surface to dry thoroughly.

Cleaner Condition

ProClean® PrepWash Concentrate

Light to moderate surface dirt

Barbecue grease

ProClean® Mildew Eliminator

Mildew

DeckScapes™ Stain & Sealer Remover

Weathered, gray wood

Old Paint & Stain

DeckScapes™ Deck Wash

Mildew stain

Algae stain

Weathered wood (bleaches wood)

Gray wood (bleaches wood)

DeckScapes Revive®

Tannin Bleed

Nail stain

Weathered wood (restores color)

Gray wood (restores color)

Mill Glaze