

# ProClassic®

## Waterborne Interior Acrylic High Gloss

B21W00351 Extra White


**SHERWIN  
WILLIAMS®**

### CHARACTERISTICS

**ProClassic Waterborne Interior Acrylic Enamel** is a high quality coating that provides a durable, non-yellowing finish. The excellent flow and leveling characteristics result in a smooth, rich finish equal to an alkyd enamel.

#### Project Uses:

- trim areas and molding
- cabinets-doors-windows
- kitchen's-baths-locker rooms
- laundry rooms
- high traffic areas

#### Substrates:

- drywall-plaster
- paneling-wood
- metal
- concrete-masonry

**Color:** Most Colors

To optimize hide and color development, always use the recommended P-Shade primer

**Coverage:** 350-400 sq.ft. per gallon  
@ 4 mils wet; 1.5 mils dry

#### Drying Time, @ 77°F, 50% RH:

Touch: 1 Hour

Recoat: 4 Hours

Drying and recoat times are temperature, humidity, and film thickness dependent

**Finish:** 55+ units @ 20°  
80+ units @ 60°

#### Tinting with CCE only:

Base:	oz. per gallon	Strength:
Extra White	0-5	SherColor

#### Extra White B21W00351

(may vary by color)

#### V.O.C. (less exempt solvents):

116 grams per litre; 0.97 lbs. per gallon  
As per 40 CFR 59.406

**Volume Solids:** 37 ± 2%

**Weight Solids:** 47 ± 2%

**Weight per Gallon:** 9.89 lbs

**Flash Point:** N/A

**Vehicle Type:** Acrylic

**Shelf Life:** 36 months unopened

### COMPLIANCE

As of 03/03/2020, Complies with:

<b>OTC</b>	Yes
<b>OTC Phase II</b>	Yes
<b>SCAQMD</b>	No
<b>CARB</b>	Yes
<b>CARB SCM 2007</b>	Yes
<b>Canada</b>	Yes
<b>LEED® v4 &amp; v4.1 Emissions</b>	No
<b>LEED® v4 &amp; v4.1 V.O.C.</b>	No
<b>EPD-NSF® Certified</b>	No
<b>MIR-Product Lens Certified</b>	No
<b>MPI</b>	No

### APPLICATION

Apply at temperatures above 50°F.  
No reduction needed.

#### Brush:

Use a nylon-polyester brush.

#### Roller:

For best final appearance when rolling, finish off in one direction, especially for dark colors.

Use a quality 1/4-3/4 inch nap cover.

For specific brushes and rollers, please refer to our Brush and Roller Guide on [sherwin-williams.com](http://sherwin-williams.com)

#### Spray—Airless

Pressure 2000 p.s.i.  
Tip .011-.014 inch  
.011 inch for fine finishing

### APPLICATION TIPS

Make sure product is completely agitated (mechanically or manually) before use.

Priming and application of two coats at the recommended film thickness can help where hiding of a previous coating or application to new drywall is a factor.

### SPECIFICATIONS

#### Drywall:

1 coat Premium Wall and Wood Primer  
2 coats ProClassic Waterborne Interior

**Masonry / Block:** (can be filled to provide a smooth surface or primed if it is a high pH substrate)

1 coat Loxon Acrylic Block Surfer

or

1 coat Loxon Concrete and Masonry Primer  
2 coats ProClassic Waterborne Interior

#### Metal - Steel, Aluminum, Galvanized:

1 coat All Surface Enamel Latex Primer  
2 coats ProClassic Waterborne Interior

#### Plaster:

1 coat Loxon Concrete and Masonry Primer  
2 coats ProClassic Waterborne Interior

#### Wood, Composition Board:

1 coat Premium Wall and Wood Primer  
2 coats ProClassic Waterborne Interior

If the wood has bleeding (such as tannin or knot-holes), prime with Multi-Purpose Primer.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

It is **VERY** important that a high quality primer be used under **ProClassic High Gloss Enamel** to provide a surface which will give excellent holdout allowing the **ProClassic** to develop its high gloss finish.

# ProClassic®

## Waterborne Interior Acrylic High Gloss

### SURFACE PREPARATION

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

#### **Caulking:**

Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.

#### **Drywall:**

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

#### **Masonry, Concrete, Cement, Block:**

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete and Masonry Primer.

### SURFACE PREPARATION

#### **Mildew:**

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.

#### **Plaster:**

Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.

#### **Wood:**

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

### CAUTIONS

For interior use only  
Protect from freezing.  
Non-photochemically reactive.

Before using, carefully read **CAUTIONS on label**

Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

HOTW 03/03/2020 B21W00351 14 116  
FRC,SP

### CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.