


**SHERWIN
WILLIAMS®**

Waterborne Acrylic Dryfall- Eg-Shel

B42W00002 White

CHARACTERISTICS

Waterborne Acrylic Dryfall is a water based, light reflective white coating that falls dry in ten feet. Fallout can be swept up for easy cleanup of work area.

Features:

- Overspray cleans up easily
- Ten foot dry fallout
- Interior use
- High light reflectance
- Light Reflectance White 84%
- Flash Rust Resistant
- Suitable for use in USDA inspected facilities

For use on properly prepared:

Structural Steel, Galvanized Metal, Drywall and Plaster, Concrete and Masonry and Wood.

Recommended for use in:

Warehouses, Industrial, commercial, and institutional buildings, Textile mills, Manufacturing facilities, Gymnasiums, Parking garage ceilings not exposed to direct weathering.

Finish: 15-25° @60°
Color: White

Recommended Spreading Rate per coat:

Wet mils: 7.0-11.0
Dry mils: 2.8-4.4
Coverage: 145-228 sq. ft. per gallon

Theoretical Coverage: 641 sq. ft. per gallon
@ 1 mil dry

Approximate spreading rates are calculated on volume solids and do not include any application loss.

Drying Schedule @ 7.0 mils wet, @ 50% RH:

Drying, and recoat times are temperature, humidity, and film thickness dependent. Dry fall characteristics will be affected at temperatures below 77°F (25°C) or above 50% RH.

	@55°F	@77°F	@110°F
To touch	45 min.	30 min.	20 min.
To handle	1 hour	45 min.	30 min.
To recoat	2 hours	1 hour	1 hour
To cure	2 days	4 hours	3 hours
Dry Fall out	10-20 ft.	10 ft.	10 ft.

Tinting with CCE only:

White: 0-2 ounces per gallon
Not controlled for tinting strength check color before using.

White B42W00002

(may vary by color)

V.O.C. (less exempt solvents):

70 grams per litre; 0.58 lbs. per gallon

As per 40 CFR 59.406

Volume Solids: 40 ± 2%
Weight Solids: 53 ± 2%
Weight per Gallon: 10.55 lb
Flash Point: N/A
Vehicle Type: Acrylic
Shelf Life: 36 months, unopened

COMPLIANCE

As of 07/14/2021, Complies with:

OTC	Yes
OTC Phase II	Yes
S.C.A.Q.M.D.	No
CARB	Yes
CARB SCM 2007	Yes
CARB SCM 2020	No
Canada	Yes
LEED® v4 & v4.1 Emissions	No
LEED® v4 & v4.1 V.O.C.	No
EPD-NSF® Certified	No
MIR-Manufacturer Inventory	No
MPI®	Yes

APPLICATION

Temperature:

minimum 50°F / 10°C
maximum 110°F / 43°C
air, surface, and material
At least 5°F above dew point

Relative humidity: 75% maximum

The following is a guide. Changes in pressures and tip sizes may be needed for proper spray characteristics. Always purge spray equipment before use with listed reducer. Any reduction must be compatible with the existing environmental and application conditions.

Reducer: Water

Airless Spray:

Pressure 2800 p.s.i.
Hose 1/4 inch I.D.
Tip .017-.019 inch
Filter 60 mesh

Conventional Spray:

Gun Binks 95
Fluid Nozzle 63C
Air Nozzle 63 PB
Atomization Pressure 60 p.s.i.
Fluid Pressure 50 p.s.i.

Reduction: Not recommended
Brush: Not recommended
Roller Cover: Not recommended

If specific application equipment is listed above, equivalent equipment may be substituted.

Make sure product is completely agitated (mechanically or manually) before use.

Apply paint at the recommended film thickness and spreading rate as indicated. Application of coating above maximum or below minimum recommended spreading rate may adversely affect coating performance. Spreading rates are calculated on volume solids and do not include an application loss factor due to surface profile, roughness, or porosity of the surface, skill, and technique of the applicator, method of application, various surface irregularities, material lost during mixing, spillage, overthinning, climatic conditions, and excessive film build.

Stripe coat crevices, welds, and sharp angles to prevent early failure in these areas. When using spray application, use a 50% overlap with each pass of the gun to avoid holidays, bare areas, and pinholes. If necessary, cross spray at a right angle.

SPECIFICATIONS

Steel:

1 coat Pro Industrial Pro-Cryl Primer or Pro Industrial DTM Primer/Finish or Kem Bonds HS or Zinc Clad Primer
1-2 coats Waterborne Acrylic Dryfall

Aluminum:

1-2 coats Pro Industrial Waterborne Dryfall

Aluminum (Water Based Primer):

1 coat Pro Industrial Pro-Cryl Primer
1-2 coats Waterborne Acrylic Dryfall

Concrete Block (CMU):

1 coat Pro Industrial Heavy Duty Blockfiller or Loxon Acrylic Block Surfer
1-2 coats Waterborne Acrylic Dryfall

Concrete-Masonry-Plaster:

1 coat Loxon Concrete & Masonry Primer (if needed)
or Loxon Conditioner (if needed)
1-2 coats Waterborne Acrylic Dryfall

Drywall:

1-2 coats Waterborne Acrylic Dryfall

Galvanizing:

1-2 coats Waterborne Acrylic Dryfall

Pre-Finished Siding Interior: (Baked-on finishes)

1 coat Bond-Plex Waterbased Acrylic or DTM Bonding Primer
1-2 coats Waterborne Acrylic Dryfall

Previously Painted:

1-2 coats Waterborne Acrylic Dryfall

Wood, interior:

1 coat Premium Wall & Wood Primer
1-2 coats Waterborne Acrylic Dryfall

The systems listed above are representative of the product's use, other systems may be appropriate. Other primers may be appropriate.

Waterborne Acrylic Dryfall - Eg-Shel

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Do not use hydrocarbon solvents for cleaning.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer-sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Iron & Steel - Minimum surface preparation is Hand Tool Clean per SSPC-SP2. Remove all oil and grease from surface per SSPC-SP1. For better performance, use Commercial Blast Cleaning per SSPC-SP6. Prime any bare steel within 8 hours or before flash rusting occurs. Primer required.

Aluminum - Remove all oil, grease, dirt, oxide and other foreign material per SSPC-SP1.

Galvanizing - Allow to weather a minimum of six months prior to coating. Solvent Clean per SSPC-SP1. When weathering is not possible, or the surface has been treated with chromates or silicates, first Solvent Clean per SSPC-SP1 and apply a test patch. Allow paint to dry at least one week before testing adhesion. If adhesion is poor, brush blasting per SSPC-SP16 is necessary to remove these treatments. Rusty galvanizing requires a minimum of Hand Tool Cleaning per SSPC-SP2, prime the area the same day as cleaned.

Concrete Block - Surface should be thoroughly clean and dry. Air, material and surface temperatures must be at least 55°F (13°C) before filling. Use Pro Industrial Heavy Duty Block Filler or Loxon Acrylic Block Surfer. The filler must be thoroughly dry before topcoating.

Masonry - All masonry must be free of dirt, oil, grease, loose paint, mortar, masonry dust, etc. Clean per SSPC-SP13/Nace 6/ ICRI No. 310.2R, CSP 1-3. Poured, troweled, or tilt-up concrete, plaster, mortar, etc. must be thoroughly cured at least 30 days at 75°F. Form release compounds and curing membranes must be removed by brush blasting. Brick must be allowed to weather for one year prior to surface preparation and painting. Prime the area the same day as cleaned. Weathered masonry and soft or porous cement board must be brush blasted or power tool cleaned to remove loosely adhering contamination and to get to a hard, firm surface. Apply one coat Loxon Conditioner, following label recommendations.

Wood - Surface must be clean, dry, and sound. Prime with recommended primer. Knots and pitch streaks must be scraped, sanded and spot primed before full coat of primer is applied. All nail holes or small openings must be properly caulked. Sand to remove any loose or deteriorated surface wood and to obtain a proper surface profile.

SURFACE PREPARATION

Previously Painted Surface - If in sound condition, clean the surface of all foreign material. Smooth, hard or glossy coatings and surfaces should be dulled by abrading the surface. Apply a test area, allowing paint to dry one week before testing adhesion. If adhesion is poor, additional abrasion of the surface and/or removal of the previous coating may be necessary. Retest surface for adhesion. If paint is peeling or badly weathered, clean surface to sound substrate and treat as a new surface as above. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Drywall- Must be clean and dry. All nail heads must be set and spackled. Joints must be taped and covered with joint compound. Spackled nail heads and tape joints must be sanded smooth and all dust removed prior to the application of paint.

Mildew- Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach-water solution.

SAFETY PRECAUTIONS

Before using, carefully read **CAUTIONS** on label. Refer to the Safety Data Sheets (SDS) before use. Overspray landing on hot surfaces may adhere to these surfaces. Immediately remove overspray from hot surfaces before adhesion occurs. Note that surface temperatures can be higher than air temperature.

During the early stages of drying, the coating is sensitive to rain, dew, high humidity and moisture condensation. Plan painting schedules to avoid these influences during the first 16-24 hours of curing.

FOR PROFESSIONAL USE ONLY.

Published technical data and instructions are subject to change without notice. Contact your Sherwin-Williams representative for additional technical data and instructions.

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.

HOTW 07/14/2021 B42W00002 28 70
FRC