



**SHERWIN  
WILLIAMS®**

As of 05/01/09, Complies with:			
OTC	Yes	LEED® Clv2.0	Yes
SCAQMD	Yes	LEED® NCv2.2	Yes
CARB	Yes	LEED® CSv2.0	Yes
MPI Spec #	No	LEED® H	Yes
NAHB	Yes		

108.38

**PREMIUM**

**WALL & WOOD PRIMER**

**INTERIOR LATEX PRIMER**

**B28W8111**

PREVIOUSLY PREP RITE® CLASSIC INTERIOR LATEX PRIMER

<p><b>FOR THE SMOOTHEST FINISH</b></p>	<p><b><u>CHARACTERISTICS</u></b></p>	<p><b><u>SURFACE PREPARATION</u></b></p>
<p><b>Our Finest Primer</b></p> <ul style="list-style-type: none"> <li>Assures uniform color and gloss of topcoat on <b>walls, doors</b> and <b>trim</b></li> <li>Assures consistent and maximum sheen of <b>enamel</b> topcoats on surfaces of varying porosity</li> <li>Quick drying</li> <li>Fast sanding</li> <li>Excellent coverage</li> <li>Quality sealer under wallcovering</li> </ul> <p><b>For use on these surfaces:</b></p> <ul style="list-style-type: none"> <li>Wood</li> <li>Drywall</li> <li>Plywood</li> <li>Primed Metal</li> <li>Previously painted surfaces</li> </ul> <p><b>Sanding</b> Premium Wall &amp; Wood Primer is designed to sand quickly, to a powder, in 2 hours. Use medium to fine sandpaper and lightly sand. Little effort is required for a smooth finish.</p>	<p><b>Color:</b> White</p> <p><b>Coverage:</b> 400 sq ft/gal @ 4 mils wet; 1.8 mils dry</p> <p><b>Drying Time, @ 77°F, 50% RH:</b> Drying and recoat times are temperature, humidity and film thickness dependent.</p> <p>Touch: 30 minutes</p> <p>To Sand: 2 hours</p> <p>Recoat: 2 hours</p> <p><b>Flash Point:</b> N/A</p> <p><b>Finish:</b> 0-5 units @ 85°</p> <p><b>Tinting</b> - For best color development, use the recommended "P"-shade primer. If desired, up to 4 oz per gallon of Blend-A-Color Toner can be used to approximate the topcoat color. Check color before use.</p> <p><b>Vehicle Type:</b> Vinyl Acrylic Latex <b>B28W08111</b></p> <p><b>VOC:</b> 41 g/L; 0.34 lb/gal</p> <p><b>Volume Solids:</b> 46 ± 2%</p> <p><b>Weight Solids:</b> 65 ± 2%</p> <p><b>Weight per Gallon:</b> 12.8 lb</p> <p>Must be topcoated within 14 days with architectural latex or oil finishes or wallcovering. Apply wallcovering after 24 hours drying.</p> <p>When spot priming on some surfaces, a non-uniform appearance of the final coat may result, due to differences in holdout between primed and unprimed areas. To avoid this, prime the entire surface rather than spot priming.</p>	<p><b>WARNING!</b> Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.</p> <p>Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with an appropriate primer sealer.</p> <p><b>Drywall</b> - Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.</p> <p><b>Masonry, Concrete, Cement</b> - All surfaces must be cured, usually 30 days, before painting. Remove all form release and curing agents. Fill rough surfaces to provide a smooth surface. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete &amp; Masonry Primer. Masonry surfaces must be dry before priming. Moisture content must be 15% or lower, and the pH between 5 and 9.</p>

108.38

# PREMIUM WALL & WOOD PRIMER

## INTERIOR LATEX PRIMER B28W8111



**SHERWIN  
WILLIAMS®**

### SURFACE PREPARATION

**Plaster** - Must be cured, usually 30 days, and hard. If painting cannot wait, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with water and allow to dry before painting.

#### **Wood, Hardboard**

Sand bare wood to a fresh surface. Patch holes and imperfections with wood filler/putty and sand smooth. Remove sanding dust. When used as an enamel undercoater, Premium Wall & Wood Primer is designed to minimize wood grain raising.

On woods that present potential knot or tannin bleeding, such as redwood and cedar, use Multi-Purpose Oil-Based Primer instead.

#### **Mildew**

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.

#### **Caulking**

Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.

### APPLICATION

Apply at temperatures above 50°F.  
No reduction necessary.

#### **Brush**

Use a nylon/polyester brush.

#### **Roller**

Use a 3/8" - 3/4" nap cover.

#### **Spray - Airless**

Pressure ..... 2000 psi

Tip ..... .013"-.017"

#### **HVLP**

Cap ..... #3-4

Reduction ..... as needed up to 10%

### CLEANUP INFORMATION

Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.

### CAUTIONS

For interior use only.  
Protect from freezing.

#### LABEL CAUTIONS

**CRYSTALLINE SILICA.** Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Adequate ventilation required when sanding or abrading the dried film. If adequate ventilation cannot be provided wear an approved particulate respirator (NIOSH approved). Follow respirator manufacturer's directions for respirator use. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **DELAYED EFFECTS FROM LONG TERM OVEREXPOSURE.** Abrading or sanding of the dry film may release crystalline silica which has been shown to cause lung damage and cancer under long term exposure. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**  
HOTW 05/13/2009 B28W08111 03 00

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative to obtain the most recent Product Data Sheet.