

Product Data Sheet



PRATT & LAMBERT PAINTS
Never compromise®

Pro-Hide® Silver Interior Latex High Build Topcoat

Z8910 – Eggshell

Pro-Hide® Silver Interior High Build Latex Eggshell is ideal for filling and surfacing imperfections in new or existing drywall construction. When spray applied, Pro-Hide® Silver High Build Latex Eggshell will provide a smooth and uniform finish over drywall paper and joints, while minimizing imperfections such as fuzz, sanding grooves (on a smaller scale), nicks and pinholes.

- High build paint
- Smooth uniform finish
- Ideal for filling and surfacing imperfections in new or existing drywall construction

Recommended Uses

Recommended for interior drywall, ceilings, masonry, plaster, galvanized metal, and previously painted surfaces

Recommended Systems

Drywall

1 coat Pro-Hide® Silver Interior Latex Wall Primer
1 or 2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Masonry

1 coat Pratt & Lambert® Masonry Primer
1 or 2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Aggregate Block

1 coat Pratt & Lambert® Acrylic Block Filler
1 or 2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Plaster (cured 30+ days)

1 coat Pro-Hide® Gold Interior/Exterior Waterborne Primer
1 or 2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Wood

1 coat Pro-Hide® Gold Interior/Exterior Waterborne Primer
1 or 2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Metal

1 coat Pratt & Lambert® Acrylic Waterborne Shopcoat Primer
1 or 2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Previously Painted Surfaces

2 coats Pro-Hide® Silver Interior Latex Eggshell High Build

Technical Data

Vehicle: Vinyl Acrylic Latex

Finish: 15-25 units @ 85°

Flash Point: N/A

Volume Solids: 28± 2%

Weight Solids: 41 ± 2%

Weight/Gallon: 10.1 lb

VOC (less exempt solvents): VOC: 94 g/L - 0.78 lb/gal as per 40 CFR 59.406

Spread Rate: 50-400 sq. ft. per gallon
@ 32-53 mils wet; 9-15 mils dry

Drying Time (@ 77°F, 50% R.H.):

Note: Drying times are temperature, humidity and film thickness dependant.

To Touch: 30 minutes
To Recoat: 4 hours

Color: White

Tinting: Pratt & Lambert or BAC Universal colorants

Note: For best finished appearance, tint to approximate color of finish coat. Use 1/4 of topcoat formula, not to exceed 2 oz.

Sizes: 5 Gallons

As of 3/27/13, complies with:

OTC	✓
ETC	✓
SCAQMD	✓
CARB	✓
LADCO	✓

Product Data Sheet

Surface Preparation

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

To ensure proper adhesion, the surface to be painted must be free of dirt, dust, oil, grease, wax, rust, and any other surface contaminants. Clean surface using an appropriate cleaner to remove dust and dirt. Rinse thoroughly and allow to dry. Sand or scrape surface lightly to remove any loose paint and to smooth old surfaces. Dull glossy surfaces by using 150 grit sandpaper. Fill cracks and holes with spackling paste to smooth uneven areas. When dry, sand and clean before spot priming.

Drywall: Wipe with a damp cloth to remove dust. Allow to dry. Fill cracks & holes with spackling compound and sand smooth. Joint compound must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Block: All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents, efflorescence, salts, laitance, and other foreign matter. Rough surfaces can be filled to provide a smooth surface.

Plaster: All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. Treat textured, soft, porous, or powdery plaster with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with water and allow to dry.

Wood, Pre-Primed Fiberboard, Hardboard, Plywood: Sand any exposed wood to a fresh smooth surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Remove all sanding dust.

Aluminum & Galvanized Metal: Wash with appropriate cleaner to remove any oil, grease, or other surface contamination using a water-based cleaner-degreaser. Remove all corrosion with sandpaper, steel wool, or other abrading method.

Caulking: Fill gaps between walls, ceilings, crown moldings, and other trim with latex or siliconized latex caulk after priming the surface.

Mildew: Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the mildewed area for 10 minutes. Rinse thoroughly with water and allow surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

Pro-Hide® Silver Interior Latex High Build Topcoat Z8910 – Eggshell

Application

Temperature (air, surface and material):
Apply at temperatures above 50°F.

No reduction necessary

Airless Spray:

Pressure.....	2000 psi
Tip.....	.017"-.023"
Reduction.....	Not recommended.

Brush:

Brush.....	Nylon/polyester
Reduction.....	Not recommended

Roller:

Cover.....	1/2" nap synthetic
Reduction.....	Not recommended

Tips to Improve Performance

- Clean the surface thoroughly
- Prepare the substrate to create a uniform surface
- Patch cracks, crevices, and through-wall openings using proper sealant or patch
- Fill voids and openings around windows and doors using proper sealant or patch
- Caulk as needed using quality latex or paintable siliconized latex caulk or sealant

Cautions

- **Prevent from freezing**
- **Not for use on horizontal surfaces, or where water will collect**

Clean Up

Clean spills & splatters immediately with soap & warm water. Clean hands & tools immediately after use with soap & warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting. Follow manufacturer's safety recommendations when using mineral spirits.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.