# Solo®

# 100% Acrylic Interior-Exterior Flat A74-Series



## **CHARACTERISTICS**

Solo 100% Acrylic Interior-Exterior creates a scrubbable finish that is resistant to burnishing, wearing, and blocking. Solo is excellent choice for specifications where 100% acrylic interior finishes are required. It is designed for use on doors, trim, walls, & shutters. Solo can be applied to surfaces with a pH up to 13.

Color: Most Colors To optimize hide and color development, always use the recommended P-Shade primer

Coverage: 350-400 sq. ft. per gallon

@ 4 mils wet; 1.6 mils dry

## Drying Time, @ 77°F (25°C), 50% RH:

Touch: 1 Hour Recoat: 4 Hours Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 0-5 units @ 85°

## Tinting with CCE only:

| oz. per | Strength:                     |
|---------|-------------------------------|
| gallon: |                               |
| 0-6     | SherColor                     |
| 4-12    | SherColor                     |
| 10-12   | SherColor                     |
|         | <b>gallon:</b><br>0-6<br>4-12 |

### Extra White A74W00051

(may vary by color)

## V.O.C. (less exempt solvents):

less than 50 grams per litre; 0.42 lbs. per gallon As per 40 CFR 59.406

**Volume Solids:**  $39 \pm 2\%$ Weight Solids: 53 ± 2% 10.99 lbs (4.99 kg) Weight per Gallon: Flash Point: NA Vehicle Type: 100% Acrylic Shelf Life: 36 months unopened WVP Perms (US): 39.46 grains/(hr ft2 in Hg)

## **Mildew Resistant**

This coating contains agents which inhibit the growth of mildew on the surface of this coating film.

## **COMPLIANCE**

As of 07/28/2020, Complies with:

| OTC                        | Yes |
|----------------------------|-----|
| OTC Phase II               | Yes |
| SCAQMD                     | Yes |
| CARB                       | Yes |
| CARB SCM 2007              | Yes |
| Canada                     | Yes |
| LEED® v4 & v4.1 Emissions  | Yes |
| LEED® v4 & v4.1 V.O.C.     | Yes |
| EPD-NSF® Certified         | No  |
| MIR-Manufacturer Inventory | No  |
| MPI®                       | Yes |

## **APPLICATION**

Apply at temperatures above 50°F (10°C). No reduction needed.

### Brush:

Use a nylon-polyester brush.

Use a 3/8 to 3/4 inch nap synthetic cover.

For specific brushes and rollers, please refer to our Brush and Roller Guide.

## Spray—Airless

Pressure 2000 p.s.i. .015-.021 inch Tip

## **APPLICATION TIPS**

Make sure product is completely agitated (mechanically or manually) before use.

## **SPECIFICATIONS**

Apply 2 topcoats of Solo directly over existing properly prepared, interior or exterior coatings, or new interior bare drywall, plaster (cured with a pH of less than 13), masonry (cured with a pH of less than 13) and nonbleeding wood.

### Interior

Drywall: Self-prime using 2 coats of Solo

1 coat ProMar 200 Zero V.O.C. Primer 2 coats Solo

Plaster: Self-prime using 2 coats of Solo

1 coat Loxon Concrete and Masonry Primer 2 coats Solo

Wood: Self-prime using 2 coats of Solo

1 coat Premium Wall and Wood Primer 2 coats Solo

### **Interior and Exterior**

Aluminum, Galvanized & Steel:(if needed)

1 coat All Surface Enamel Latex Primer 2 coats Solo

### Block:

1 coat ConFlex Block Filler

2 coats Solo

## Masonry, Cement, Stucco:

1 coat Loxon Concrete and Masonry Primer 2 coats Solo

### Exterior

## Wood, Composition Board:

1 coat Exterior Oil-Based Wood Primer

or 1 coat Exterior Latex Wood Primer

2 coats Solo

### Plywood:

1 coat Exterior Latex Wood Primer

2 coats Solo

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

## 100% Acrylic Interior-Exterior Flat

### SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

### **Aluminum and Galvanized Steel:**

Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

### Caulking:

Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.

### **Concrete Block:**

All new surfaces must be cured according to recommendations—usually about 30 days. Rough surfaces can be filled with ConFlex Block Filler to provide a smooth surface. The filler must be thoroughly dry before topcoating.

### Drywall:

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

## Masonry, Concrete, Cement:

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.

### Stucco:

Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.

### **SURFACE PREPARATION**

### Mildew:

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/ water solution.

### Steel:

Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed the same day as cleaned

### Plaster:

Must be cured, usually 30 days, and hard. If painting cannot wait, allow the surface to dry 7 days and prime with Loxon Concrete and Masonry Primer. Soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with water and allow to dry before painting.

### Vinyl or other PVC Building Products:

Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, prime with appropriate white primer. Do not paint vinyl with any color darker than the original color. Do not paint vinyl with a color having a Light Reflective Value (LRV) of less than 56. Painting with darker colors lower than an LRV of 56 may cause vinyl to warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.

## Wood, Plywood, Composition Board:

Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining.

**Exterior:** If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.

**Interior:** If staining persists, spot prime severe areas with 1 coat of Multi-Purpose Oil-Based Primer.

## **CAUTIONS**

Protect from freezing. Non-photochemically reactive.

Before using, carefully read **CAUTIONS** on label

CRYSTALLINE SILICA Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Adequate ventilation required when sanding or abrading the dried film. If adequate ventilation cannot be provided wear an approved particulate respirator (NIOSH approved). Follow respirator manufacturer's directions for respirator use. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. FIRST AID: In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. DELAYED EFFECTS FROM LONG TERM OVEREXPOSURE. Abrading or sanding of the dry film may release crystalline silica which has been shown to cause lung damage and cancer under long term exposure. WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.

HOTW 07/28/2020 A74W00051 23 17 FRC,SP

## **CLEANUP INFORMATION**

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.