

# 2000 SERIES

## PREMIUM GRADE INTERIOR SATIN

ULTRA BRIGHT WHITE/PASTEL BASE, DEEPTONE BASE, ACCENT BASE

# CONCO PAINTS

Pro Technology...Engineered For The Job®

Conco® 2000 Series Interior Satin Acrylic Latex is a premium grade coating designed for custom homes, residential re-paints and renovations. Conco 2000 Series features excellent hide, outstanding touch-up and a washable, scrubbable coating that provides an exceptional finish. This premium grade product ensures that you - and every home you work on - make a statement.

## FEATURES

- Premium grade coating designed for custom homes, residential re-paints and renovations
- Ideal for painting new wall board or drywall, plaster, masonry, wood, and metal
- Provides excellent hide, outstanding touch-up and a washable coating with an exceptional finish
- Fast dry time allows you to recoat in just 4 hours
- Easily applied using a brush, roller, or airless sprayer
- Spatter resistant formula
- Soap and water cleanup
- Backed by a 100% Satisfaction Assured Warranty

## TECHNICAL DATA \*

|                                |  |
|--------------------------------|--|
| Vehicle:                       | Vinyl Acrylic/Acrylic  |
| Finish:                        | 5-15 units @ 85°   |
| Flash Point:                   | N/A  |
| Weight Solids:                 | 52% ± 2%   |
| Volume Solids:                 | 40% ± 2%   |
| Dry Time (@ 77°F and 50% R.H.) |  |
| To Touch:                      | 30 Min – 1 Hour  |
| To Recoat:                     | 4 Hours  |
| Weight Per Gallon:             | 10.74 lb/gal   |
| VOC:                           | 130 g/L – 1.09 lb/gal<br>as per 40 CFR 59.406                            |
| Spread Rate:                   | 300-400 sq.ft. per gallon<br>(dependent on surface texture and porosity) |
| Film Thickness:                | @ 4 mils wet; 1.4 mils dry   |
| Sizes:                         | Gallons, Fives   |

\*Technical Data based on Bright White/Pastel base

## APPLICATION

Do not apply at air, surface or product temperatures below 50°F or when air or surface temperatures may drop below 50°F within 24 hours.

### Spray – Airless

Pressure 2000 psi  
Tip .015" - .019"

May be thinned up to 1 pint of water per gallon for spray application.

### Brush

Use a quality nylon/polyester brush.

### Roller

Use a 3/8" nap synthetic roller cover.

## RECOMMENDED SYSTEMS

### New Wallboard/Drywall

- 1 Coat Conco P001 Interior Drywall PVA Primer/Sealer
- 2 Coats Conco 2000 Series Interior Satin Latex

### Wood

- 1 Coat Conco P007 Int/Ext All Surface Acrylic Stain Blocking Primer
- 2 Coats Conco 2000 Series Interior Satin Latex

### Plaster (Allow to cure for 30 days)

- 1 Coat Conco P007 Int/Ext All Surface Acrylic Stain Blocking Primer
- 2 Coats Conco 2000 Series Interior Satin Latex

### Masonry /Aggregate Block (Allow to cure for 30 days)

- 1 Coat Conco P007 Int/Ext All Surface Acrylic Stain Blocking Primer
- Or
- 1 Coat Conco P001 Interior Drywall PVA Primer/Sealer
- Or
- 1 Coat Conco P9511 Int/Ext Acrylic Latex Block Filler (For filled effect)
- 2 Coats Conco 2000 Series Interior Satin Latex

### Metal

- 1 Coat Conco P801 DTM Acrylic Prime & Finish
- 2 Coats Conco 2000 Series Interior Satin Latex

## TIPS FOR BETTER PERFORMANCE

- Stir well before using
- If using more than one package of the same color, mix together before applying to ensure uniform color
- Clean the surface thoroughly
- Sand surface smooth to ensure an even surface
- Patch cracks, crevices and trough-wall openings using a proper sealant or patch



# SURFACE PREPARATION

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

To ensure proper adhesion, all surfaces must be clean, dry and free from dirt, wax, grease, oil, chalk, mildew and loose or peeling paint. Nail holes, cracks and other surface imperfections should be properly filled, sanded smooth and dusted clean. All mildew and mold must be completely and thoroughly removed. Glossy surfaces must be sanded and dusted clean. Always wear a properly selected and fitted NIOSH/MSHA approved dust mask or respirator when sanding.

## New Wallboard or Drywall

Fill cracks and holes with spackling compound and sand smooth. Joint compound must be cured and sanded smooth. Remove all sanding dust. Prime with one coat of Conco P001 Drywall P.V.A. Primer/Sealer.

## Wood

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Remove dust and prime with one coat of Conco P007 Int/Ext All Surface Acrylic Stain Blocking Primer.

## Plaster (allow to cure for 30 days)

Must be dry, cured and hard with a pH<9.5. Treat textured, soft, porous or powdery plaster with a solution of 1 pint of vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry. Prime with one coat of Conco P007 Int/Ext All Surface Acrylic Stain Blocking Primer or one coat of P001 Drywall P.V.A. Primer/Sealer.

## Masonry/Aggregate Block (allow to cure for 30 days)

Remove all surface contamination and dust by washing with an appropriate cleaner and allow to dry. Prime with one coat of Conco P007 Int/Ext All Surface Acrylic Stain Blocking Primer or one coat of Conco P001 Drywall P.V.A. Primer/Sealer. For a filled effect use Conco P9511 Acrylic Latex Block Filler as a first coat.

## Metal

Remove all contaminants and rust. Wipe clean using an appropriate cleaner. Prime with Conco P801 DTM Acrylic Prime and Finish.

## Caulking

Fill gaps between walls, ceilings, crown moldings and other trim with latex or siliconized latex caulk after priming the surface.

## Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

# CLEAN UP/DISPOSAL

- Clean hands and tools with warm, soapy water
- Promptly wipe up spills and spatters with a damp cloth
- In event of a spill, use sand or kitty litter to absorb the spilled product
- Dispose of empty container or unused portion in accordance with local, state, and federal regulations
- After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment
- Follow manufacturer's safety recommendations when using mineral spirits

# CAUTIONS

- For interior use only
- Keep from freezing
- Not for use on roofs, floors or decks
- Not for use on horizontal surfaces where water may collect

# WARRANTY

If this product, when applied according to label instructions, fails to perform to your complete satisfaction, we will either replace an equivalent quantity of product free of charge or refund the purchase price, upon presentation of proof of purchase. This warranty does not include labor or costs associated with labor for the application of any product. This warranty gives you specific legal rights, and you may have other rights, which vary state to state.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Conco Paints. Information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Conco Paint retailer or sales representative to obtain the most recent Product Data Sheet.