



P015 High Build Interior Latex Primer/Surfacer

Conco® P015 High Build Interior Latex Primer/Surfacer fills and surfaces minor surface defects such as paper fuzz, nicks, pinholes and sanding grooves, saving a considerable amount of prep time. It evens the porosity between drywall paper and joints to ensure an even topcoat sheen. Over a Level 4 drywall surface, it will provide a

Recommended Uses

- New Construction
- Remodel & Rehab Projects
- Drywall, Plaster and Masonry
- Under Latex and Alkyd Topcoats

Performance Benefits

- Excellent Professional Quality
- High Build- Apply up to 25 mils Wet
- Eliminates Need for Extensive Surface Prep
- Fills & Smooths Minor Imperfections
- Enables a Level 5 Finish
- Ensures a Smooth, Even Topcoat

Recommended Systems

New Wallboard/ Drywall

1 coat Conco® P015 High Build Interior Latex Primer/Surfacer
1 or 2 coats Conco® Interior Latex or Alkyd Paint

Plaster, Masonry, Stucco (allow to cure for 30 days)

1 coat Conco® P015 High Build Interior Latex Primer/Surfacer
1 or 2 coats Conco® Interior Latex or Alkyd Paint

Technical Information

Finish:	Flat 0-5 @ 85°
Colors:	White
Drying Time (@ 77°F, 50% Rel. Humidity)	
To Touch:	1 hour
To Recoat:	4 Hours
Spread Rate:	64 - 400 Sq. Ft. /Gal (dependent upon applied thickness)
Film Thickness:	4.0 - 25.0 mils wet 1.8 - 11.0 mils dry
Volume Solids:	44% ± 2%
Weight Solids:	63% ± 2%
Weight per Gallon:	12.78 lbs
Vehicle Type:	Vinyl Acrylic
Flash Point:	Not Applicable
V.O.C. Level:	VOC: 94 g/l- 0.78 lb/gal as per 40 CFR 59.406
Reduction:	Not Recommended
Cleanup:	Soap and Water
Size:	Available in Fives

Warranty:

20 YEAR LIMITED WARRANTY: If this product, when applied according to label instructions, fails to perform to your complete satisfaction, upon presentation of proof of purchase to the store where the product was purchased we will, as your exclusive remedy, either replace an equivalent quantity of product free of charge or refund the purchase price. This warranty covers paint that is applied according to label instructions and excludes failure due to improper surface preparation, structural defects, or failure of the previous paint. This warranty does not include (1) labor or costs associated with labor for the application of any product and/or (2) any indirect, special, incidental or consequential damages with labor for the application of any product and/or (2) any indirect, special, incidental or consequential damages.

Surface Preparation

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Preparation

To ensure proper adhesion, all surfaces must be clean, dry and free from dirt, wax, grease, oil, chalk, mildew and loose or peeling paint. Nail holes, cracks and other surface imperfections should be properly filled, sanded smooth and dusted clean. All mildew and mold must be completely and thoroughly removed. Glossy surfaces must be sanded and dusted clean. Always wear a properly selected and fitted NIOSH/MSHA approved dust mask or respirator when sanding.

New Wallboard / Drywall

Fill cracks and holes with spackling compound and sand smooth. Joint compound must be cured and sanded smooth. Remove all sanding dust.

Wood

Sand any exposed wood to a fresh, smooth surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Remove all sanding dust.

Plaster (allow to cure for 30 days)

Must be dry, cured and hard with a pH <9.5. Treat textured, soft, porous or powdery plaster with a solution of 1 pint of vinegar to 1 gallon of water. Repeat until surface is hard, rinse with clear water and allow to dry.

Masonry/Aggregate Block (allow to cure for 30 days)

Remove all surface contamination, including heavy chalk, efflorescence, laitance and concrete dust, by washing with an appropriate cleaner and allow to dry.

Caulking

Fill gaps between walls, ceilings, crown moldings and other trim with latex or siliconized latex caulk after priming the surface.

Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

Application

Thoroughly agitate before using. Due to the high solids content of this material, a power agitator is recommended. You must use an airless sprayer to achieve a high build finish. Use a 1 GPM or larger direct immersion airless sprayer. Sprayers with suction tubes will also work but will prime slower. Screens & filters must be clean and in place. Float a small amount of water on top of paint to avoid drying of paint and formation of skin. Apply only enough material to cover undesirable surface imperfections. Do not exceed 25 mils wet. Frequently measure film thickness with wet mil gauge for most consistent application.

Cleanup Information

Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.



CONCO PAINTS
Pro Technology... Engineered For The Job™

P015 High Build Interior Latex Primer/Surfer

Application

- Do not apply at air, surface or product temperatures below 50°F or when air or surface temperatures may drop below 50°F within 24 hours.

Spray – Airless (For High Build Finish)

Pressure.....2000-2500 psi
Tip......525 or larger (10" spray with 0.025" tip)
Pump.....1 GPM or larger

Brush

Use a quality nylon/polyester brush.

Roller

Use a 1/2"-1 1/2" nap synthetic roller cover.

Tips for Better Performance

- Clean the surface thoroughly
- Sand surface smooth to ensure an even surface
- Prepare the substrate
- Patch cracks, crevices and through-wall openings using proper sealant or patch
- Fill voids and openings around windows and doors using proper sealant or patch
- Caulk as needed using quality latex or siliconized latex caulk or sealant

Cautions

- For interior use only
- Keep from freezing
- Not for use on roofs, floors or decks
- Not for use on horizontal surfaces where water may collect

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Conco Paints. Information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Conco Paint retailer or sales representative to obtain the most recent Product Data Sheet.