

**CONCO PAINTS**

Pro Technology... Engineered For The Job™

**Product Data Sheet****P008****QUICK DRY STAIN BLOCKING  
PRIMER/SEALER**

Conco® Interior Alkyd Quick Dry Stain Blocking Primer/Sealer is an interior, odorless, oil-based product that seals in odors and blocks dried water stains, smoke stains, grease, ink, pencil and many other difficult stains. It is ideal for occupied settings where odor is a concern and the performance of an oil-based primer is necessary.

**Recommended Uses**

- Ideal for fire restoration work
- For use over drywall, plaster, wood, ceiling tiles, paneling, galvanized metal, aluminum and previously painted surfaces
- Recommended for occupied settings where odor is a concern – hospitals, schools, offices, restaurants

**Performance Benefits**

- Odorless
- Seals in smoke stains and odors
- Blocks water sensitive stains such as dried water stains and wood tannins
- Blocks variety of common stains – grease, ink, crayon, more
- Excellent hide
- Sands easily
- Bonds readily to glossy and chalky surfaces
- Quick dry-recoat in 2 hours
- Assures uniform topcoat

**Certification**

- Master Painters Institute- MPI # 45

**Recommended Systems****Wallboard/Drywall/Ceiling Tiles**

1 coat Conco® P008 Odorless Alkyd Quick Dry Stain Blocking Primer/Sealer

1 or 2 coats Conco® Interior Latex or Alkyd Paint

**Wood**

1 coat Conco® P008 Odorless Alkyd Quick Dry Stain Blocking Primer/Sealer

1 or 2 coats Conco® Interior Latex or Alkyd Paint

**Plaster/Masonry (allow to cure 30 days)**

1 coat Conco® P008 Odorless Alkyd Quick Dry Stain Blocking Primer/Sealer

1 or 2 coats Conco® Interior Latex or Alkyd Paint

**Galvanized Metal/Aluminum**

1 coat Conco® P008 Odorless Alkyd Quick Dry Stain Blocking Primer/Sealer

1 or 2 coats Conco® Interior Latex or Alkyd Paint

**Technical Information**

**Finish:** Flat, 0-5 @ 85°

**Color:** White

**Drying Time** (@ 77°F, 50% Rel. Humidity)

**To Touch:** 30 minutes

**To Recoat:** 2 hours

**Coverage Sq Ft/Gal** 350-400 sq.ft. /gal.  
(Dependant upon surface texture and porosity)

**Volume Solids:** 47% ± 2%

**Weight Solids:** 73% ± 2%

**Spread Rate:**

**Wet Mills:** 4.0

**Dry Mills:** 2.0

**Weight per Gallon:** 12.4 lbs.

**Vehicle Type:** Copolymer

**Flash Point:** 100° F, PMCC

**V.O.C. Level:** 397 g/L; 3.3 lb/gal

**Reduction:** Not Recommended

**Cleanup:** Mineral Spirits

**Size:** Available in Ones and Fives

**Warranty:**

If this product, when applied according to label instructions, fails to perform to your complete satisfaction, we will either replace an equivalent quantity of product free of charge or refund the purchase price, upon presentation of proof of purchase. This warranty does not include labor or costs associated with labor for the application of any product. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Revised 1/15

## Surface Preparation

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

## Preparation

To ensure proper adhesion, all surfaces must be clean, dry and free from surface dirt, wax, grease, oil, mildew and loose or peeling paint. Surface imperfections should be properly filled, sanded smooth and dusted clean. Always wear a properly selected and fitted NIOSH/MSHA approved dust mask or respirator when sanding. All mildew and mold must be completely and thoroughly removed. Glossy surfaces do not require sanding.

### Wood

Sand any exposed wood to a fresh, smooth surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Remove all sanding dust.

### Plaster (Allow to cure 30 days)

Must be dry, cured and hard with a p.H. less than 9.5. Soft, porous or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with water and allow to dry before priming.

### Galvanized Metal/Aluminum

Remove all contaminants and rust. Wipe clean using an appropriate cleaner

### Mildew

Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

## Application

**STIR WELL BEFORE USING.** Do not thin. Roll at package consistency. May be applied by natural bristle brush, medium nap synthetic or mohair roller, or airless spray. Use clean spray equipment only. If another alkyd product is sprayed prior to this primer, completely flush the spray equipment with mineral spirits prior to spraying. If not properly cleaned, a higher than normal amount of P008 primer will need to be circulated through the unit before developing the desired spray pattern. After spot priming stains, test a small area for bleeding. Apply a small area with the chosen topcoat. If stains are solvent sensitive, spot prime those areas with Conco® P007 All Surface 100% Acrylic Interior/Exterior Water Base Stainblocking Primer.

## Cleanup Information

Clean spills, spatters and equipment with mineral spirits. Follow manufacturer's safety instructions when using mineral spirits.



**CONCO PAINTS**  
Pro Technology... Engineered For The Job™

## P008 ALKYD QUICK DRY STAIN BLOCKING PRIMER/SEALER

## Application

Do not apply at air, surface or material temperatures below 50°F or when air or surface temperatures may drop below 50°F within 24 hours.

### Spray-Airless

Pressure.....2500-3000 psi  
Tip Size......013" - .017"  
Hose.....1/4" ID

### Brush

Use a quality natural bristle brush.

### Roller

Use a 1/4" – 1/2" nap synthetic or mohair roller cover

## Tips For Better Performance

- Stir well before using
- Clean the surface thoroughly
- Sand surface smooth to ensure an even surface
- Prepare the surface to create a uniform surface
- Patch cracks, crevices, and through-wall openings using proper sealant or patch
- Fill voids and openings around windows and doors using proper sealant or patch
- Caulk as needed using quality latex or siliconized latex caulk or sealant

## Cautions

- Use clean spray equipment only. Completely flush equipment with mineral spirits prior to spraying for best spray pattern development.
- Interior use only
- Non-photochemically reactive

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Conco Paints. Information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Conco Paint retailer or sales representative to obtain the most recent Product Data Sheet.